



SEWFINE INTERIOR PRODUCTS  
2280 So Lipan Street  
Denver, CO 80223  
720-287-2127

WE STRONGLY RECOMMEND NEW PANEL MOUNTING CLIPS FOR ALL PANELS. The mounting clips we sell are STRONGER than the original clips, and will easily secure your new panels into place. We have tested original clips, and many aftermarket clips, and none work as successfully as the specific clip Sewfine carries. All Sewfine panels install with hidden clips. The push-thru pins in 80-83 will not work properly. On 80-83 Westy models, the aluminum channel at the top edge of the slider must be removed.

#### **VANAGON SLIDER PANEL INSTALLATION:**

Install NEW mounting clips.

Install Plastic latch cover. BE CAREFUL NOT TO SNAP THE TOP CORNER OF THE PANEL. The plastic cover needs some lubrication to slide on. If your panel is CLOTH, wet the plastic with very soapy water and slide into place. If your panel is vinyl, lubricate the plastic and the vinyl with WD 40, silicone spray, or soapy water; then slide into place. A small rubber mallet could help tap (gently) the last bit into place if the plastic does not slide all the way on.

Remove the "weather strip" at the rear edge of the slider opening (on the body of the Van).

Get inside the Van with the panel (with clips installed). Close the sliding door.

Put the panel in place and start snapping clips in place on the bottom edge.

Next, start snapping clips up both sides of the slider. When you reach the center of the panel, snap the clips in the center of the panel into place.

Now, locate the screw mounting point at the rear edge of the panel. (85-91 only).

Take a piece of chalk and mark the screw hole on the front of the panel. (85-91 only)

Using an awl (pointy tool) push the point thru the front of the panel. Take a flashlight and locate the screw hole on the slider door, and continue pushing the awl thru the body hole to align the panel into place. (85-91 only)

Remove the awl and put the screw into place. (85-91 only).

80-84 slider door panels installs the same way, just without the screw.

Then, just continue snapping clips in place. Install the door handle and you're done

### **VANAGON FRONT DOOR PANELS INSTALLATION:**

Install Panel Clips and mount panel to make sure the panel is straight and square on the door.

DO NOT cut out the entire door release opening. Instead, slowly dip away from the middle until the mechanism is clear of the fabric. Then, put your bezel on.

Cut a small circle around the window crank shaft JUST UNTIL IT CLEARS THE SHAFT. Then, install the window crank.

Slide on plastic vent in lower corner.

### **HATCH PANEL INSTALLATION:**

Push Thru pins will not work on the early models (80-83)). These must be mounted with Hidden clips.

A small cut is on the bottom edge of the panel, but the fabric floats over it. Some Westy models have an inside hatch release button located in this spot. If you are going to utilize this latch release, make a small cut in the vinyl, and fold to the backside of the panel to allow clearance for the release button.

### **SIDE REAR QTR PANEL INSTALLATION:**

Front 2/3 mounts with hidden clips. Back edge mounts in Westy models attach with 2 stock screw studs. All other models need the 3 pc screw/cap/washer.

**WWW.SEWFINEPRODUCTS.COM**

**1-800-SEWFINE**

FOR ALL YOUR VANAGON INTERIOR NEEDS:

SEAT COVERS

SLEEPER CUSHIONS

DOOR PANELS

REPLACEMENT FOAM

CARPET KITS

SCREENS

HEADLINERS

CURTAINS